

BENTLEY

CAR TYPE	TYPE	SIZE	ET	H / PCD	CENTER	WHEEL CODE	KIT CODE	NOTE
CONTINENTAL FLYING SPUR 01/2005→ (Type 3W) PCD 5 / 112 - Hub Ø57 - Screw M14 x 1.5 17mm HEX								
	365	9.0 x 20	30	5 / 112	C.R.	365 900 001	065 457 571	
	501	9.0 x 20	30	5 / 112	C.R.	501 900 001	035 457 571	
	503	9.0 x 20	30	5 / 112	C.R.	503 900 001	065 457 571	
	381	9.0 x 22	25	5 / 112	C.R.	381 902 001	035 457 571	
	503	9.0 x 22	24	5 / 112	C.R.	503 902 001	065 457 571	
CONTINENTAL GT 09/2002→ (Type 3W) PCD 5 / 112 - Hub Ø57 - Screw M14 x 1.5 17mm HEX								
	365	9.0 x 20	30	5 / 112	C.R.	365 900 001	065 457 571	
	501	9.0 x 20	30	5 / 112	C.R.	501 900 001	035 457 571	
	503	9.0 x 20	30	5 / 112	C.R.	503 900 001	065 457 571	
	381	9.0 x 22	25	5 / 112	C.R.	381 902 001	035 457 571	
	503	9.0 x 22	24	5 / 112	C.R.	503 902 001	065 457 571	

All wheels with center "C.R." must be used with the aluminium center ring which is included in the fitting kit. The fitting kit is for a set of 4 wheels. It contains 16/20 or 24 Screw or Nut, together with 4 aluminium center rings where required.